

Sense Clean



30V DC, CC (Constant current), 5000lm: max 1400mA (42W)

Sense Panel:

Sense Driver Kit:

Sold separately

Sense Panels and Driver Kits:

	IP	SDCM (Steps)	CRI (Ra)	BA (°)	SENSE 3000lm DRIVER KIT PHASE DIM (700mA)	SENSE 4000lm DRIVER KIT NON DIM (1050mA)	SENSE 5000lm DRIVER KIT NON DIM (1400mA)	SENSE 3000lm DRIVER KIT DALI (700mA)	SENSE 4000lm DRIVER KIT DALI (1050mA)	SENSE 5000lm DRIVER KIT DALI (1400mA)
SENSE PRISM 5000lm 3000K	44	3	80	90	2650lm/UGR<17 21W/126lm/W	3750lm/UGR<17 31,5W/119lm/W	4500lm/UGR<19 42W/107lm/W	2650lm/UGR<17 21W/126lm/W	3750lm/UGR<17 31,5W/119lm/W	4500lm/UGR<19 42W/107lm/W
SENSE PRISM 5000lm 4000K	44	3	80	90	2750lm/UGR<17 21W/131lm/W	3750lm/UGR<17 31,5W/119lm/W	4600lm/UGR<19 42W/110lm/W	2750lm/UGR<17 21W/131lm/W	3750lm/UGR<17 31,5W/119lm/W	4600lm/UGR<19 42W/110lm/W
SENSE PRISM 5000lm 3000K	44	3	90	90	2450lm/UGR<17 21W/117lm/W	3500lm/UGR<17 31,5W/111lm/W	4200lm/UGR<19 42W/100lm/W	2450lm/UGR<17 21W/117lm/W	3500lm/UGR<17 31,5W/111lm/W	4200lm/UGR<19 42W/100lm/W
SENSE PRISM 5000lm 4000K	44	3	90	90	2650lm/UGR<17 21W/126lm/W	3600lm/UGR<17 31,5W/114lm/W	4400lm/UGR<19 42W/105lm/W	2650lm/UGR<17 21W/126lm/W	3600lm/UGR<17 31,5W/114lm/W	4400lm/UGR<19 42W/105lm/W

Above efficiency calculations are excl. driver.
Incl. driver: 7-14% loss depending on driver.

Rev 14.04.19

NO: Kan kun installeres av en registrert installasjonsvirksomhet.
EN: Only to be installed by an authorized electrician.
FR: Doit être installé par un électricien autorisé.
NL: Mag alleen geïnstalleerd worden door een bevoegde elektricien.
DE: Dieses Produkt darf nur durch autorisiertes Personal (z. B. Elektro-Installateur) angeschlossen und in Betrieb genommen werden.
FI: Asentaa saa vain valtuutettu sähköasentaja

NO: Skru av strømmen før montering.
EN: Turn off power before installing.
FR: Couper le courant avant l'installation.
NL: Stroom uitschakelen voor u het toestel installeert.
DE: Vor Installationsarbeiten den Strom abschalten.
FI: Sammuta virta ennen kytkemistä

- | | | | |
|---|--|--|--|
| <p>NORWAY SG Armaturen AS
Skytterheia 25
N-4790 Lillesand
Tel: +47 37 50 03 00
firmapost@sg-as.no
www.sg-as.no</p> | <p>SWEDEN SG Armaturen AB
Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se</p> | <p>FRANCE SG Lighting SA/NV
Tel: +33(0) 4 94 93 00 00
info.france@sglighting.fr
www.sglighting.net</p> | <p>GERMANY SG Leuchten GmbH
Tel: +49 40 23 99 44 59
info@sg-leuchten.de
www.sg-leuchten.de</p> |
| <p>FINLAND SG Armaturen Oy
info@sg-oy.fi
www.sg-oy.fi</p> | <p>DENMARK SG Armaturen A/S
Tel: +45 70 70 72 13
info@sg-as.dk
www.sg-as.dk</p> | <p>BENELUX SG Lighting SA/NV
Tel: +32(0) 15 20 72 71
info.benelux@sglighting.net
www.sglighting.net</p> | <p>INTERNATIONAL SG Lighting Co Ltd.
Tel: +86 769 88 49 20 88
cindy@sgdgc.com
www.sg-as.com</p> |

